# Verbeterblad voor HP1 bij BaZ nr 35/18 Block for HP1 to NL NtM 35/18

Delete section 15.6.3.1 and replace by:

### 15.6.3.1 Approaches and Borkum roads

### Anchorage 9

This anchorage is normally used by channel-bound vessels waiting to enter Eemshaven, but can also be used for general use.

## **Emergency anchorage**

This anchorage is available only for channel-bound vessels which already are sailing in the channel and are informed that the Eemshaven is closed

#### Borkum-Reede

This anchorage is available for general use.

On anchoring in or leaving this location all vessels should report this to the appropriate VTS station.